CHAPTER 18.0 TABLE OF CONTENTS

18.1 HOSTIL	ATTACHMENTS E ENVIRONMENT PLAN
18.5.2	Hardware
18.5 INSPE	CTION AND MATERIAL LIMITATIONS
18.4 MARK	ING AND POSTING
18.3.2 18.3.3 18.3.4	Preparation Review/Approval Requirements Hostile Environment Plan Contents Additional Procedures Hostile Environment Plan Distribution
	LE ENVIRONMENT PLAN
18.2.2	Prerequisite Review As Low As Reasonably Achievable First Priority
18.2 EQUIP	MENT AND OPERATIONS REVIEW
18.1.1 18.1.2	Normal Operations Special Provisions
18.1 SCOPE	3
18.0 HOISTI	NG AND RIGGING IN HOSTILE ENVIRONMENTS2
PAGINATIO	N TABLE1
TABLE OF C	ONTENTS1

PAGINATION TABLE

Page	Release.	Date
1	44	09/28/2004
2	44	09/28/2004
3	44	09/28/2004
4	44	09/28/2004
5	44	09/28/2004
6	44	09/28/2004

Rev 1 Page 2

18.0 HOISTING AND RIGGING IN HOSTILE ENVIRONMENTS

18.1 SCOPE

18.1.1 Normal Operations

Hoisting and rigging (H&R) activities can usually be accomplished where the environment will allow normal operations with access for hands-on equipment contact. In such situations, operations, maintenance, inspections, and tests shall be done in accordance with regular provisions of this manual.

18.1.2 Special Provisions

This section contains the special provisions for H&R operations and equipment in hostile environments where standard operating, maintenance, inspection, or test procedures cannot be followed as a result of radiation or contamination, toxic/hazardous chemicals or gasses, or temperature extremes.

18.2 EQUIPMENT AND OPERATIONS REVIEW

18.2.1 Prerequisite Review

The H&R equipment or operations shall be reviewed by a designated person to determine compliance with the requirements of this manual. If it is determined to be impossible or unreasonable for the requirements of this manual to be met as a result of hostile environmental conditions, then a hostile environment plan shall be prepared to document alternative compliance methods and procedures.

18.2.2 As Low As Reasonably Achievable

All H&R operations shall be consistent with the U.S. Department of Energy's radiation exposure policy of "as low as reasonably achievable" (ALARA).

18.2.3 First Priority

Safety of personnel shall remain the first priority.

18.3 HOSTILE ENVIRONMENT PLAN

18.3.1 Preparation

A hostile environment plan shall be prepared by a designated person and shall cover operations, equipment, inspection, testing, and maintenance. See Attachment 18.1 "Hostile Environment Plan."

18.3.2 Review/Approval Requirements

As a minimum, the plan shall be reviewed and approved (signed and dated) by responsible management at the facility where the crane/hoist or other equipment is located and responsible management of an overview organization (such as Safety or Quality Assurance). Depending upon the site-specific organizational structure, the following review/approvals are recommended:

1. *Facility manager

- 2. *Responsible management, oversight organization (safety or quality assurance/control)
- 3. Responsible operations manager
- 4. Equipment custodian
- 5. Cognizant engineer.
 - *Review/approval is mandatory.

18.3.3 Hostile Environment Plan Contents

The plan shall address only those actions or features that require deviation from the requirements of this manual because of a hostile environment, but shall contain the following information as a minimum:

- 1. The specific requirement(s) that are not in compliance
- 2. The difference between the requirement and actual conditions
- 3. Justification for not meeting this manual's requirements
- 4. A statement of actions or features to be used to compensate for the differences
- 5. Specific maintenance, inspections, and tests to be performed whenever access is possible
- 6. Replacement or retirement criteria for equipment that is designed to operate with minimum or no maintenance.

18.3.4 Additional Procedures

Detailed operation, inspection, testing, and maintenance procedures that state specific requirements and acceptance criteria shall be prepared based upon the hostile environment plan.

1 18.3.5 Hostile Environment Plan Distribution

The facility manager shall ensure that the approved hostile environment plan is distributed as follows:

- 1. U.S. Department of Energy, Richland Operations Office Hoisting and Rigging Program Manager, MSIN R3-78 (for information)
- 2. Equipment operators, maintenance organizations, and other organizations/personnel affected by the plan
- 3. Equipment history file.

NOTE: Hostile environment plans in the equipment history file shall be readily available to appointed personnel.

Rev 1 Page 4

18.4 MARKING AND POSTING

Equipment that requires a hostile environment plan should be posted "Hostile Environment Plan-Special Maintenance and Operating Instructions."

18.5 INSPECTION AND MATERIAL LIMITATIONS

18.5.1 Hardware

Handling fixtures, rigging, and rigging accessories shall be marked, tagged, load tested, and otherwise qualified, as appropriate, in accordance with this manual before being exposed to the hostile environment.

18.5.2 Polyester

Polyester (rope or webbing) slings shall not be used in a radiation area.

18.5.3 Nylon

Nylon (rope or webbing) slings should not be used in a radiation area unless absolutely necessary. When it is necessary to use a nylon sling in a radiation area, the responsible manager shall ensure radiation exposure does not exceed 100,000 rads during the life of the sling.

ATTACHMENT 18.1 -1 TYPICAL HOSTILE ENVIRONMENT PLAN

Buildir	ng:	Location:					
				(e.g., overhead top-running			
bridge	and trolley; top-run	ning bridge with underh	nung hoist; jib crane; mon	norail hoist; overhead hoist)			
Capaci	ty (main and auxili	ary):					
Power method:			(e.g., hand	operated, electrical powered)			
Manuf	acturer:						
1.a.	Paragraph number of the H&R manual requirement that will not be met:						
	(Copy the applical	ole paragraph)					
1.b.	Difference between manual requirement and what is to be allowed by this plan:						
1.c.	Justification for not meeting the manual requirement:						
1.d.	Actions or feature	s to compensate for diffe	erences:				
informa	ation regarding any ent.	special design, mainten		•			
		CTIONS TO THIS PLA	N AS REQUIRED. (e.g.	., 2.a THROUGH 2.d).]			
APPR	OVALS						
Facility	Manager(signa	ture/date) Mana	ager, Oversight Organiza	tion:(signature/date)			
•	Other:(signa	ture/date)					

* Modify approval cycle, see paragraph 18.3.2

Place approved Hostile Environment Plan in Equipment History File

Make readily available to operating and maintenance personnel-

THIS PAGE LEFT INTENTIONALLY BLANK